

**ADB Set Top Box**

**Instructions to program the remote for One Button Commands**

**Real Time Macro - One Button Programming**

You can program your ADB Set-top Box remote control to issue a sequence of commands at the press of one button.

For example, you may want to turn off your TV, DVD and the set top box at the same time. Any sequence you regularly use can be reduced to one keystroke for your convenience. A key that is programmed with a Macro works through all modes (provided it is accessible in that mode). You can install a Macro on any key except for the Mode keys and SHIFT key.

**To set up a Macro:**


Follow these 3 steps in the order given. You must have your TV code ready. Check our list of TV brand codes if you cannot find this code listed in your TV user manual.

1. To program the remote to your TV:
  - Press TV.
  - Press and hold SHIFT until it flashes twice.
  - Enter the 4 digit code.
  - Press Power. If the TV goes off it is programmed. If the TV does not go off, follow the same steps but try another TV code.
2. To run the volume of your TV from the Set Top Box (STB) mode:
  - Press STB.
  - Press and hold SHIFT until STB flashes twice.
  - Press 993,
  - Press TV. To try it, push STB and then volume up or down.
3. To control your TV power from the STB mode:
  - Push STB.
  - Press and hold shift until STB flashes twice.
  - Press 995,
  - Press Power,
  - Press TV,
  - Press Power,
  - Press STB.
  - Press and hold shift until STB flashes twice.

**Definition:**

Macro = A programed key that represents a list of commands, actions, or keystrokes. You can create a macro so that you can press a single button to perform a whole series of actions.

**THE REMOTE CONTROL**



**Please Note:** The remote control buttons are highly sensitive and while you may select the button only once, it may respond as if you hit it multiple times.