

PROGRAMMING THE REMOTE CONTROL TO RUN THE TV:

RCA Silver Remote Control:

1. Turn on component you want to operate (TV, VCR, etc).
2. Press and hold component button you want to program (**TV**, for example). While holding component button, press and hold **ON/OFF** until **Indicator Light** on remote turns on, then release both buttons.
3. Point the remote at component. Press & release **PLAY**, then wait 5 seconds or until indicator on the remote stops flashing.

At this point, the remote is searching for correct code to program. If, after 5 seconds, the component you want to operate does not turn OFF, press **PLAY** again to search the next set of codes. Continue pressing **PLAY** until component turns off or you have searched through all codes. There are 20 total sets of codes. If the component does not turn off after pressing PLAY 20 times, then remote cannot be programmed to operate that component.

If component you want to control DOES TURN OFF:

1. Press and release **REVERSE**, then wait 2 seconds. Repeat this step until device turns back ON.
2. Press and hold **STOP** until **Indicator Light** on remote turns off.

